



1

Para perforar el lavamanos a 4" o 8".
 * Lavamanos vista superior.

*To make faucet perforations on the lavatory for 4" and 8".
 * Top view of the lavatory.*

2

Haga una pequeña perforación solo con la broca guía, buscando el punto céntrico del orificio en el que desee instalar la grifería.
 * imagen del lavamanos por debajo.

*Make a small hole using the guide drill bit, aiming for the center of the hole where you want to install the faucet.
 * Down view of the lavatory.*

3

Perfore los orificios insinuados para instalar la grifería usando la copa sierra de 1 1/4". Esto se debe hacer con el lavamanos hacia arriba. Este proceso se repite para las perforaciones que la grifería requiera.

*Drill the holes guided by the marks made by the drill bit, using the 1 1/4" cup saw. This should be done drilling the front side of the lavatory, repete this process for the othe holes required for your faucet. * Isometric view of the lavatory.*

4

Se procede a instalar la grifería después de haber perforado perfectamente el orificio. (Lavamanos con grifería instalada).
 * imagen del lavamanos lateral.

*We proceed to install the faucet after drilling the hole and perfectly polished with 60 grit sandpaper (Lavatory with taps installed).
 * Lateral view of the lavatory.*